





MN220043\_20221024

i




MN220043\_20221024



1



1




2



3

MN220043\_20221024

2 Ø 38 mm / 1.5 in



2 Ø 39 - 41 mm  
1.54 - 1.61 in

Ø 42 - 46 mm  
1.65 - 1.81 in

Ø 47 - 51 mm  
1.85 - 2.01 in




Ø mm / in  
1. -  
2. -  
3. 39 / 1.54  
4. 40 / 1.57  
5. 41 / 1.61



Ø mm / in  
1. 42 / 1.65  
2. 43 / 1.69  
3. 44 / 1.73  
4. 45 / 1.77  
5. 46 / 1.81




Ø mm / in  
1. 47 / 1.85  
2. 48 / 1.89  
3. 49 / 1.93  
4. 50 / 1.97  
5. 51 / 2.01




MN220043\_20221024


3




4



MN220043\_20221024






**5**



MN220043\_20221024


6



MN220043\_20221024



Follow the steps in the manual CM-03-E to activate the blind:



For more information and support:



[rtube.nl/red1920](https://rtube.nl/red1920)