

eve flare 

Get started

Kako začnete?

Počnimo

Get started • Kako začnete? • Počnimo

①

Use the supplied power adapter to connect the charging station to a power outlet. Place Eve Flare on the charging station to commence charging. A full charge takes approximately 6 hours.

Uporabite priloženi napajalnik za priključitev polnilne postaje v električno vtičnico. Postavite napravo Eve Flare na polnilno postajo, da začnete polniti. Celotna polnitev traja približno 6 ur.




Upotrijebite priloženi adapter napajanja za spajanje stanice za punjenje na vanjsku utičnico. Položite Eve Flare na stanicu za punjenje kako biste započeli s punjenjem. Potrebno je približno 6 sati da se uređaj napuni do kraja.

i

It is normal that Eve Flare shines a little brighter when used on the charging station.

Običajno je, da naprava Eve Flare nekoliko bolj sveti, ko jo uporabljate na polnilni postaji.

Normalno je da Eve Flare sija svetlije kada se koristi na stanicama za punjenje.




②

Push the POWER button to switch on or off. Push the MODE button to cycle through colors.

Pritisnite gumb POWER (VKLOP/IZKLOP) za vklop ali izklop. Pritisnite tipko MODE (NAČIN), da se premikate po barvah.

Pritisnite gumb POWER za vključevanje ali izključevanje. Pritisnite gumb MODE kako boste kružili kroz boje.




③

Download the Elgato Eve app from the App Store.

Prenesite aplikacijo Elgato Eve iz trgovine App Store.

Preuzmite aplikaciju Elgato Eve iz trgovine aplikacijama App Store.




④

Open the Elgato Eve app and tap Add Accessory. Eve will now guide you through the setup process.

Odprite aplikacijo Elgato Eve in se dotaknite Add Accessory (Dodaj dodatno opremo). Aplikacija Eve vas bo zdaj vodila skozi postopek namestitve.

Otvorite aplikacijo Elgato Eve i pritisnite Add Accessory. Eve će vas sada provesti kroz postupak postavljanja.

Add Accessory



If you have already set up another accessory, go to Settings in Eve to add Eve Flare to your home.

Če ste že nastavili drugo dodatno opremo, pojdite na nastavitve Eve, da dodate napravo Eve Flare v svoj dom.

Ako ste već instalirali drugi pribor, idite na postavke Eve kako biste dodali Eve Flare na vašu početnu stranicu.

Hereby, Elgato Systems declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EC. The declaration of conformity is available at www.elgato.com/doc

Frequency range: 2402 - 2480 MHz

Max RF e.i.r.p power < 3dBm

Temperature range: 3 °C - 50 °C

Product: 10EAX4101 / 10EAX8301 • Model: 20EAX9901 • Part: 51EAX9902

S tem družba Elgato Systems izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in drugimi ustreznimi določbami Direktive 2014/53/ES. Izjava o skladnosti je na voljo na www.elgato.com/doc

Obseg frekvence: 2402 - 2480 MHz

RF moč: < 3 dBm EIRP

Temperaturni obseg: 3 °C - 50 °C

Izdelek: 10EAX4101 / 10EAX8301 • Model: 20EAX9901 • Del: 51EAX9902


Ovime tvrtka Elgato Systems izjavlja da je ovaj uređaj u skladu s bitnim zahtjevima i drugim relevantnim odredbama Direktive 2014/53/EK. Izjava o skladnosti je dostupna na www.elgato.com/doc

Raspon frekvencija: MHz: 2402 - 2480 MHz

Snaga radiofrekvencije: < 3 dBm EIRP

Temperaturni raspon: 3 °C - 50 °C

Proizvod: 10EAX4101 / 10EAX8301 • Model: 20EAX9901 • Dio: 51EAX9902



Please keep your HomeKit Setup Code in a safe place. You need it to securely add Eve to your home, and nobody but you has a copy.

Prosimo, hranite kodo za namestitev HomeKit na varnem mestu. Potrebujete jo, da varno dodate Eve v svoj dom in nihče, razen vas nima kopije.

Čuvajte svoj kučni kod za instalacijo na sigurnom. Potreban vam je kako boste sigurno dodali aplikacijo Eve na svojo početnu stranico i nitko osim vas nema kopiju.



eve flare 



Room • Soba • Prostor:

Notes • Opombe • Napomene:

